

## DRIVEABILITY - GAS

### P0351-IGNITION COIL # 1 PRIMARY CIRCUIT — Continued

POSSIBLE CAUSES		
PCM		
TEST	ACTION	APPLICABILITY
1	<p>Ignition on, engine not running. With the DRBIII®, read DTCs and record the related Freeze Frame data. Is the Good Trip Counter displayed and equal to zero?</p> <p>Yes → Go To 2</p> <p>No → Refer to the INTERMITTENT CONDITION Symptom (Diagnostic Procedure). Perform POWERTRAIN VERIFICATION TEST VER - 5.</p>	All
2	<p>Turn the ignition off. Disconnect the Ignition Coil harness connector. Ignition on, engine not running. With the DRBIII®, actuate the ASD Relay. Using a 12-volt test light connected to ground, probe the (F42) ASD Relay Output circuit at the coil rail harness connector. Does the test light illuminate brightly?</p> <p>Yes → Go To 3</p> <p>No → Repair the excessive resistance or short to ground in the (F42) ASD Relay Output circuit. Inspect the related fuses and repair as necessary. Perform POWERTRAIN VERIFICATION TEST VER - 5.</p>	All
<b>CAUTION: Stop All Actuations</b>		
3	<p>Turn the ignition off. Disconnect the Ignition Coil harness connector.</p> <p><b>NOTE: The resistance of the 2.4L Primary Ignition Coil is 0.53 to 0.63 of an ohm and the resistance of a 4.0L Primary Coil Rail is 0.51 to 0.61 of an ohm at 70°F (21.1°C).</b></p> <p>Measure the resistance of the primary ignition coil. Is the resistance value within the listed specifications?</p> <p>Yes → Go To 4</p> <p>No → Replace the ignition coil. Perform POWERTRAIN VERIFICATION TEST VER - 5.</p>	All
4	<p>Turn the ignition off. Disconnect the Ignition Coil harness connector. Using a 12-volt test light connected to 12-volts, probe the Ignition Coil Control circuit. Crank the engine for 5 second while observing the test light. What is the state of the test light while cranking the engine?</p> <p>Brightly blinking. Replace the Ignition Coil. Perform POWERTRAIN VERIFICATION TEST VER - 5.</p> <p>ON constantly. Go To 5</p> <p>OFF constantly. Go To 6</p>	All

## P0351-IGNITION COIL # 1 PRIMARY CIRCUIT — Continued

TEST	ACTION	APPLICABILITY
5	<p>Turn the ignition off.</p> <p>Disconnect the PCM harness connectors.</p> <p>Measure the resistance between the Ignition Coil Control circuit and ground.</p> <p>Is the resistance below 100 ohms?</p> <p>Yes → Repair the short to ground in the Ignition Coil Control circuit. Perform POWERTRAIN VERIFICATION TEST VER - 5.</p> <p>No → Go To 7</p>	All
6	<p>Turn the ignition off.</p> <p>Disconnect the PCM harness connectors.</p> <p>Measure the resistance of the Ignition Coil Control circuit from the Ignition Coil connector to the PCM connector.</p> <p>Is the resistance below 5.0 ohms?</p> <p>Yes → Go To 7</p> <p>No → Repair the open in the Ignition Coil Control circuit. Perform POWERTRAIN VERIFICATION TEST VER - 5.</p>	All
7	<p><b>NOTE: Before continuing, check the PCM harness connector terminals for corrosion, damage, or terminal push out. Repair as necessary.</b></p> <p>Using the schematics as a guide, inspect the wire harness and connectors. Pay particular attention to all Power and Ground circuits.</p> <p>If there are no possible causes remaining, view repair.</p> <p>Repair</p> <p>Replace and program the Powertrain Control Module per Service Information.</p> <p>Perform POWERTRAIN VERIFICATION TEST VER - 5.</p>	All