



RockJock® Professional OffRoad Products presents:

CE-9300 1" Body Lift

Installation Instructions

Fits

Fits: Jeep YJ, TJ & LJ Wranglers & Unlimiteds from 1987-2006.

Kit Includes

- 11) CE-9300A.....Aluminum Body Lift Spacer
- 6) EE-5072CH8.....1/2"-13 x 4 1/2" Bolt
- 6) EE-50WUSSH.....1/2" Flat Washer
- 5) EE-4360CH8.....7/16"-14 x 3 3/4" Bolt
- 5) EE-43WUSSH.....7/16" Flat Whasher
- 2) CE-9300B.....Polyurethane Grille Spacer



Required Tools

- Complete set of hand tools.

Instructions

- 1) Disconnect battery.
- 2) Unbolt all original body mount bolts.
- 3) Jack body up off of frame on one side first. Place the new 1" body pucks on top of the cone shaped factory rubber body mounts.
- 4) With some general adhesive, mount the 1" grill spacers under the factory rubber grille snubbers, one on each side of radiator/grille assembly.
- 5) Hand tighten all of the new body bolts at this time.
- 6) Repeat steps 3. 4 & 5 on the other side.
- 7) Torque all of the new body bolts to 60 ft. lbs.
- 8) Check radiator to fan clearance and fan to fan shroud clearance. If you are not using a set of Currie CE-9200 1" lifted motor mounts, you must redrill the fan shroud mounts 1" lower and remount the fan shroud so that it will .
- 9) Re-connect battery.
- 10) Re-check all body bolts after the first 100 miles.



Currie Enterprises / RockJock Professional Off Road Products
382 N. Smith Ave., Corona, Ca. 92880
Ph (714) 528-6957 - F (951) 549-0267
www.rockjock4x4.com

